

Uniseal Hole Size Chart



<u>Uniseal pipe size</u>	<u>Hole Saw size</u>
1/2"	1 1/4
3/4"	1 1/4
1"	1 3/4
1 1/4"	2
1 1/2"	2 1/2
2"	3
3"	4

Quick tips:

- It is much easier to slide the PVC through the uniseal if you lubricate the pipe with soapy water or windex
- If you are still having trouble, it can help slide the pvc pipe through the uniseal if you bevel the edges with a file or grinder

Bulkhead Hole Size Chart (ABS)



<u>ABS bulkhead pipe size</u>	<u>Hole Saw size</u>
1/2"	1 1/4
3/4"	1 3/8
1"	1 5/8
1 1/4"	2
1 1/2"	2 3/8
2"	2 7/8
3"	4

Notes:

- The bulkhead should be hand tightened with the gasket on the inside of the tank
- Bulkheads can be threaded or slip